

TT-S1

TT-SI

Ancillary board for TTC2000

Ancillary board intended to control an extra load when using the TTC2000 controller.

- Maximum 25 A load (appr. 17 kW)
- Easy installation and start-up

- Potential free relay output
- For control of auxiliary contactor

TT-S1 is an ancillary board intended to control an extra load connected to TTC2000. The board controls a contactor which activates or deactivates the heating load. For best function, the load connected to TT-S1 should be of equal size to the load connected to TTC2000 (triac).

Function

On increasing heat demand, TTC2000 will primarily increase the triac-controlled output. When this reaches 100% the ancillary board will be activated and the triac output will be reduced to 0%. If there is a need for more heating, the triac-controlled output will be activated again.

Easy to install and connect

TTC2000 is prepared to plug-in TT-S1. It detects if TT-S1 is installed and automatically adapts the control function accordingly. No adjustments are necessary. Carefully locate the board so that the connectors mate and the TT-S1 legs align with the mounting holes (see picture on the following page).

Connect the two terminals to the contactor that controls the basic heating load.

 $\ensuremath{\mathsf{TTC2000}}$ and $\ensuremath{\mathsf{TT-S1}}$ must have separate, equal-sized loads.

N.B. The supply should be wired via the fan stat, the high temperature limit switch etc.




Technical data

Supply voltage Supplied by the connector (TTC2000)
Control signal Supplied by the connector (TTC2000)

Output Single pole closing relay, 5 Å, 230 V AC (terminals 1 and 2)
Controls load via contactor. Maximum load via contactor 25 Å

(€

This product carries the CE-mark. More information is available at www.regincontrols.com.



* Connection example: The Ancillary board is connected in series with a pressure switch (P), an overheating protection (T), and a contactor of an electric heater.

Installation

